A Product Manager XPR Readers



CONFIGURATION SOFTWARE FOR THE XPRO AND XSMART RANGES



The **Product Manager XPR Readers** is a new user-friendly software designed to manage the Xpro and Xsmart readers.

You can set up the readers as well as update the firmware or make any new settings you would like to add or remove. The software is available in 7 languages and compatible with Windows operating systems

Senal port (COM) COM	 ReaderConfiguration po 	baved proved			Disconnected
Interface	W54 -	SETWISHDEPAULTS			1
Change the Reader Configuration password	New password		*	Passed leights Exhibition Use lefter, nor characters like (1995)*	there and special
12.5 MHz Protocol	CSN, no encryption	e e ASB finit)			
Report configuration card					
Decklight					
Blue	100%	100			
Green	100%	100			
Red	100%	100			
Buzzer level	52%	50			
Display name Drivker rep					


▲ Software for Xpro and Xsmart readers



The new generation of access control readers has been developed to offer more possibilities with fewer references. One reader can combine different communication protocols (Wiegand, OSDP) and different technologies (EM, Mifare, Keypad, Bluetooth, etc...), besides being upgradable according to the customer's needs.

Thanks to the Product Manager XPR Readers software you can set up the configuration (communication protocols, technologies...) you desire for your readers, as well as update their firmware or the settings afterward if needed.

🛆 Main features



CONCRUMENT PARAMENT CONCRUMENT Based Configuration parsented Interface Interface Interface Interface Configuration parsented Interface Interface Configuration parsented Interface Interface Interface Interface Interface Configuration parsented Interface Reder Interface Interface Reder Interface Interface

Settings

Once the reader is connected, you can select the settings you desire for your XPR reader(s), such as the protocol, technology, card types, etc. You can also apply specific settings: OSDP, Wiegand, Templates, and Password.

Firmware update

Once the reader is connected to the computer, you can check the latest firmware available for your reader, and it can be installed with some easy instructions.

All product specifications are subject to change without notice.

